

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

Parts and Repairs available for the Bailey Net 90 and Infi 90 Distributed Control Systems
Please call or email to check for current pricing and availability.

Part Number	Description	Quantity
6635188C	NLIM02 Daughter card	2
BRC100	Bridge Controller	2
BRC30	Bridge Controller	4
CLC01	Loop Command Single Loop Controller	0
CLC02	Loop Command Single Loop Controller	2
CLC03	Loop Command Single Loop Controller	0
6637964A1	CLC03 Loop Command Single Loop Controller Card Assembly	0
6637864E1	CLC03 Loop Command Single Loop Controller Card Assembly	2
6637864A1	CLC Loop Command Card Assembly	0
CLC04	Loop Command Single Loop Controller	0
CPC01001	Command Series Process Command Controller	1
CSC01	Loop Command Sequence Command Controller	0
CTT01	Tuning and Configuration Handheld Terminal	1
CTT02	Tuning and Configuration Handheld Terminal	5
CTT12	Tuning and Configuration Handheld Terminal (does not include power supply)	1
HPG800		1
IISAC01	Analog Control Station Manual/Auto with bypass	0
IMAMI01	Auto Manual Interface Module	0
IMAMM03	Analog Master Module, 64 inputs via up to 8 ASM0x modules, use NTAM01, NIAM02	11
IMAOM01	Analog Output Module, 8 analog outputs, 4-20mA, 1-5 vdc, 0-10 vdc, use NTAO01, NIAO01	8
IMASI02	Analog Input Module	21
IMASI03	Analog Input Module, 16 Inputs, TC, Mv, RTD, High Level, use with IMMFP0X, NTAI06, NIAI05	12
IMASI13	Analog Input Module, 16 inputs (replaced IMASI03)	9
IMASI23	Analog Input Module, 16 inputs	2
IMASM01	Analog Input Module, 4-20mA, 1-5v, 0-10v, -10 to 10vdc, use with IMAMM03, NTAI05, NIAI04	4
IMASM02	Analog Input Module 8 mv or TC inputs -100 to 100 mV, use with IMAMM03, NTAI02, NIAI02	22
IMASM03	Analog Input Module, 8 RTD inputs, 100 ohm, use with IMAMM03, NTAI04, NIAI03	5
IMASM04	Analog Input Module, 8 RTD Inputs, 10 ohm, use with IMAMM03, NTAI04, NIAI03	3

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

IMASO01	Analog Output Module, 14 Analog Outputs, 1-5vdc, 4-20mA, use with IMMFP0X, NTDI01, NIDI01	18
IMASO11	Analog Output Module (14 outputs), supports 4-20 mA 1-5V, use with NTDI01. NIDI01	1
IMCIS02	Control I/O Module, 4AI, 3DI, 4DO, 2AO, use with IMMFP0X, NTCS04, NICS01	42
IMCIS12	Control I/O Module, 4AI, 3DI, 4DO, 2AO, use with NTCS04, NICS01	19
IMCIS22	Control I/O Module	0
IMCKN01	Clock Network Module (c/w Frequency Drift Compensation)	0
IMCKN02	Clock Network Module (c/w Frequency Drift Compensation)	0
IMCOM03	Enhanced Controller Module, 4AI, 3DI, 4DO, 2AO, 190 blocks, use NTCS04, NICS01	50
IMCOM04	Advanced Controller Module, 4AI, 3DI, 4DO, 2AO, 190 Blocks, expanded functions, use NTCS04, NICS01	7
IMCPM01	Communications Port Module RS-232 and/or use with CTT02 for tuning and configuration of a single PCU	11
IMCPM02	Communications Port Module RS-232 and/or use with CTT02 for tuning and configuration of a single PCU	3
IMCPM03	Communications Port Module RS-232 and/or use with CTT02 for tuning and configuration of a single PCU	2
IMDER01	Single Drive Slave Module use with NTU-7C8 termination, NKTU01	0
IMDPM01	Dual Probe Module (Turbine Controls)	0
IMDSI02	Digital Input Module, 16 Inputs, 24vdc, 125 vdc, 120 vac, use with IMMFP0x, NTDI01, NIDI01	40
IMDSI12	Universal Digital Input Module (16 inputs), 24, 48, 125 VDC, 120 VAC (32 jumpers), use with NTDI01, NIDI01	7
IMDSI13	24 VDC Digital Input Module (16 inputs) 24 VDC Module, use with NTDI01, NIDI01 terminations	10
IMDSI14	48 VDC Digital Input Modules (16 inputs) 48 VDC Module, use with NTDI01, NIDI01	13
IMDSI15	125 VDC or 120 VAC Digital Input Module (16 inputs), 125 VDC or 120VAC (16 jumpers), use with NTDI01, NIDI01 terminations	10
IMDSI22	Universal Digital Input Module	6
IMDSM04	Pulse Input Module, 8 Pulse Inputs 0-50 KHz, use with IMMFP0x, NTDI01, NIDI01	12
IMDSM05	Digital Logic Station Interface Module, use with IMMFP0x, NTL01, NDLS02	1
IMDSO01	Digital Output Module, 8 outputs, 24 to 240 VAC 3A, use with IMMFP0x,NTDI01, NIDI01	34
IMDSO02	Digital Output Module, 24 VDC, 8 outputs, 5 to 50 VDC, 3A use with IMMFP0x, NTDI01, NIDI01	0
IMDSO03	Digital Output Module, 125 VDC 8 outputs 5 to 160 VDC, 1A, use with IMMFP0x, NTDI01, NIDI01	1

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

IMDSO04	Digital Output Module, 24 VDC 16 outputs 24VDC 250mA, use with IMMFP0x, NTDI01, NIDI01, NTDO02	14
IMDSO14	Digital Output Module, 16 channel open collector digital outputs, use with NTDI01, NIDI01	7
IMDSO15	Digital Output Module, 8 channel Onboard electro-mechanical relays, use with NTDI01, NIDI01	5
IMEDI01	Ethernet Device Interface Module	0
IMEXT01	Module Card Extender	1
IMFAI01	Isolated Analog Input	0
IMFBS01	Field Bus Module, 15 inputs, 4-20mA, 1-5, 0-10, +- 10 Vdc, smart trans, use with IMMFP0x, NTFB01, NTAI05, NIAI04	22
IMFCS01	Frequency Counter Module, 1 input from magnetic pickup, 3 to 12.5 KHz, use with IMMFP0x, NTDI01, NIDI01	9
IMFEC11	Analog Input Module (15 Inputs), supports 4-20mA, 1-5 v FSK Digital, use with NTAI05, NIAI04, NTFB01	5
IMFEC12	Analog Input Module (15 inputs) supports 4-20mA, 105 V; use with NTAI05, NIAI04 terminations	0
IMHSS01	Hydraulic Servo Module	0
IMHSS02	Hydraulic Servo Module, use with NTHS03, NTDI01, NIDI01	2
IMHSS03	Hydraulic Servo Module, Redundant Outputs to Servo Coils, 2 position feed-back from LVDT, use with NTHS03, NTDI01, NIDI01	0
IMHSS04	Hydraulic Servo Module w/ Position Control	0
IMHSS05	Hydraulic Servo Module w/ 4-20mA position control	0
IMLMM02	Logic Master Module, 8DI, 8DO, 1024 Blocks, I/o thru 64 digital I/O Modules, use NTDI01, NIDI01	2
IMMFC03	Enhanced Multi-Function Controller w/ Basic & C, 10,000 blocks and/or 4000 lines of Basic or C, I/O thru 64 I/O Modules, use NTMF01, NIMF02	1
IMMFC04	Enhanced Multi-Function Controller, 5000 blocks, I/O thru 64 I/O Modules, use NTMF01, NIMF02	11
IMMFC05	Multi-Function Controller, 2000 blocks, I/O thru 64 I/O Modules, use NTMF01, NIMF01 if required	0
IMMFP01	Multi-Function Processor, 5000 Useable Blocks and/or 2000 lines of Basic or "C" use NTMP01, NIMP01,02	26
IMMFP02	Multi-Function Processor, 10,000 Useable Blocks and/or 4000 lines of Basic or "C", use NTMP01, NIMP01/02	12
IMMFP03	Multi-Function Processor, 10,000 Useable Blocks and/or 4,000 lines of Basic or "C", use IMMPI01 if ports or stations required	4
IMMFP03	B Multi-Function Processor with Enhanced Memory, 10,000 Useable Blocks and/or 4,000 lines of Basic or "C", use IMMPI01 if ports or stations required	7
IMMFP04	Multifunction Processor Advanced	0
IMMFP05	Multi-Function Processor	2
IMMFP11	Multi-Function Processor	0
IMMFP12	Multi-Function Processor	4
IMMPC01	PC-90 Processor, 2000 blocks I/O thru 64 I/O Modules, No termination	0

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

IMMPC02	Programmable Controller c/w BASIC	0
IMMPI01	Multi-Function Processor Interface for IMMFP03 provides RS- 232C/485 ports, SAC/DCS port, use NTMP01, NIMP01/02 Requires SCSI Drive CP3020/CP3040/CP30100	4
IMMPI02	Auxiliary I/O for IMMFP03 I/O + HDD	0
IMPCC01	Programmable Controller Coupler, RS-232 Interface to Programmable Controller	0
IMQRC01	Quick Response Enhanced Controller	0
IMQRC02	Quick Response Enhanced Controller	0
IMQRS02	Quick Response Module, 4AI, 3DI, 4DO, 2AO, 12x/sec response, use with IMMFP0x, NTCS04, NICS01	0
IMQRS12	Quick Response Module, 4AI, 3DI, 4DO, 2AO, 12x/sec response, use with IMMFP0x, NTCS04, NICS01	0
IMQRS22	Quick Response Module, 4AI, 3DI, 4DO, 2AO, 12x/sec response, use with IMMFP0x, NTCS04, NICS01	1
IMRAE11	Modular RTU, Isolated IA Module	0
IMRAE12	Modular RTU, Isolated AI Module w/ Smart Transmitter Support	0
IMRAI01	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRAI02	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRAI03	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRAI04	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRAI05	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRAI06	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRAI11	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRAI12	Modular RTU, Non-Isolated Input Module 8AI, 2AO	0
IMRCC01	Modular RTU Remote Communications and Control Module	0
IMRCC02	Modular RTU Remote Communications and Control Module	0
IMRCC03	Modular RTU Remote Communications and Control Module	0
IMRDI01	Modular RTU Non-Isolated Digital Input Module 16 DI 110VDC	0
IMRDI11	Modular RTU Non-Isolated Digital Input Module 16 DI 110VDC	0
IMRDI12	Modular RTU Non-Isolated Digital Input Module 16 DI 120VDC	0
IMRDI13	Modular RTU Non-Isolated Digital Input Module 16 DI 24/48VDC	0
IMRDO01	Modular RTU Digital Output Module, 8DO	0
IMRIO02	Remote I/O Module, Extend IMMFP0x I/O Bux 10K Feet, multiple drop, use with NTRL02, 03, NIRL03	0
IMRMD01	Modular RTU Modem Leased Line V.21/V.23	0
IMSED01	Sequence of Events Digital Inputs Module, 16 Digital Inputs for SOE, control, use with IMMFP01, NTDI01, NKSD01	4
IMSER01	Sequence of Events Recorder	0
IMSER02	Sequence of Events Recorder	0
IMSET01	Sequence of Event Time Keeper Module used with INSOE01	5
IMSMS01	Stepper Motor Slave (Turbine Automation)	0
IMSPM01	Serial Port Module PCU	6
IMSPM02	Serial Port Module (w/ Infi90 Controlway)	0

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

INBIM02	Bus Interface Module, PCU to INLIM03 Communications Interface, requires INLIM03	8
INBTM01	Bus Transfer Module, LIM to Module Bus Transfer; part of INPCI02, INNPPR01	3
INDDM01	Disk Drive Module (part of INOSM01) 6640931	2
INESM01	Ethernet Server Module (Part of INOSM01) 6640468_2	0
INICT01	Infi-net to Computer Transfer Module, ICI Driver, part of INICI01	0
INICT03	Infi-net to Computer Transfer Module, ICI Driver, part of INICI03	0
INICT12	Infi-net to Computer Transfer Module	1
INIIL01	Infi-net to Infi-net Local/Remote Interface	0
INIIL02	Infi-net to Infi-net Local/Remote Interface	0
INIIR01	Infi-net to Infi-net Local/Remote Interface	0
INIIT01	Infinet to Infinet Transfer Module	4
INIIT02	Infinet to Infinet Remote Transfer Module, IIR Driver, part of INIIR01	0
INIIT03	Infinet to Infinet Transfer Module, IIL Driver, Part of INIIL02	3
INIIT12	Infinet to Infinet Transfer Module	6
INIPL01	Infi-net to Plant Loop Local/Remote Interface	0
INIPR01	Infi-net to Plant Loop Local/Remote Interface	0
INIPT01	Infi-Net to Plant Loop Local Transfer Module, IPL Driver, part of INIPL01	2
INIPT02	Infi-Net to Plant Loop Remote Transfer Module, part of INIPR01	1
INIST01	Infinet to Station Transfer Module	0
INITT01	Infinet to Terminal Transfer Module	0
INLIM03	Loop Interface Module, Plant Loop to Node Communication Interface, requires INBIM02, use NTCL01, NICL01	9
INNIS01	Network Interface Module, Infi-Net to node communications interface, requires INNPM01, use NTCL01, NICL01	32
INNIS11	Network Interface Module	0
INNIS21	Network Interface Module	0
INNPM01	Network Processing Module, PCU to INNIS01 communications interface, requires INNIS01	18
INNPM02	Network Interface Module	0
INNPM11	Network Processing Module	2
INNPM12	Network Interface Module	4
INPBS01	Parallel Bus Slave, IEEE-488 Interface, part of INICI01, INPCI02-488H; 488L	0
INPCI01	Plant Loop to Computer Interface	0
INPCI02	Plant Loop to Computer Interface	0
INPCT01	Plant Loop to Computer Transfer Module, PCI Driver, part of INPCI02	1
INPPT01	Plant Loop to Plant Loop Transfer Module, PPR Driver, part of INNPPR01	1
INPTM01	Point Table Module, point table storage, part of INPCI01	0
INSCS01	SCSI Connector Module, part of INOSM01	0
INSEM01	Sequence of Events Master Module, part of INSOE01	3
INSEM11	Sequence of Events Master Module, part of INSOE01	0
INSIM01	Serial Interface Module, RS-232 interface, part of INPCI01	0

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

INSOE01	Sequence of Events Server Node, includes SEM, NIS, and TKM modules with associated terminations and cables	0
INTKM01	Time Keeper Master, part of INSOE01	0
LMUSM02	Universal Simulation Module	4
LPS01	Position Module	2
NAMM02	Analog Master Module	7
NAMM03	Analog Master Module	10
NAOM01	Analog Output Module	16
NASI01	Analog Input Module	1
NASI02	Analog Input Module	0
NASM01	Analog Input Module	14
NASM02	Analog Input Module, 8 TC or Mv Inputs	40
NASM03	Analog Input Module, RTD 100 ohm	25
NASM04	Analog Input Module, RTD 10 ohm	0
NASO01	Analog Output Module	0
NBIM01	Bus Interface Module	11
NBIM02	Bus Interface Module	36
NBPC01	Infi-net to Infinet Transfer Module (Local	1
NBTM01	Bus Transfer Module	8
NCIS01	Control I/O Module	14
NCIS02	Control I/O Module	18
NCOM02	Controller Module	10
NCOM03	Enhanced Controller Module	95
NCOM04	Advanced Controller Module	13
NCPM01	Computer Port Module	2
NCTM01	Configuration and Tuning Module, tuning, monitoring, configuration, and diagnostics of a single PCU	12
NDCS	Option Board Part No. 6632092J1	1
NDCS	Option Board Part No. 6632092R1	2
NDCS01	Digital Control Station	0
NDCS02	Digital Control Station	0
NDCS03	Digital Control H/A Station	0
NDCS03	Digital Control H/A Station Card Assmebly 683405J1	2
NDIS01	Digital Indicator Station	0
NDIS02	Digital Indicator Station	0
NDLS01	Digital Logic Station	0
NDLS02	Digital Logic Station	2
NDLS03	Digital Logic Station	0
NDSI01	Digital Slave Input Module	2
NDSI02	Digital Input Module	6
NDSM01	Digital Input Module	12
NDSM02	Digital Input Slave	0
NDSM03	Digital Input Module	6
NDSM04	Pulse Input Module, 8 inputs 0-50 KHz	1

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

NDSM05	Digital Logic Station Module	6
NDSO01	Digital Output Module	13
NDSO02	Digital Output Module	0
NDSO03	Digital Output Module	0
NDSO04	Digital Output Module	2
NFCS01	Frequency Counter Slave	0
NGCM01	Gateway Communications Module	2
NGPI02	N90 General Purpose Interface (foreign devices, PLCs)	0
NGPI03	N90 General Purpose Interface (foreign devices, PLCs)	0
NGPI04	N90 General Purpose Interface (foreign devices, PLCs)	0
NHSS01	Hydraulic Servo Module	1
NLBS01	Local Bypass Station	0
NLIM01	Loop Interface Module	0
NLIM02	Loop Interface Module	16
NLIM03	Loop Interface Module	0
NLIS01	Loop Interface Slave	9
NLMM01	Logic Master Module	0
NLMM02	Logic Master Module	6
NLSM02	(replaced by INPCT01) Plant Loop to Computer Transfer Module	3
NMFC01	Multi-Function Controller, 2000 blocks, I/O thru 64 slaves	7
NMFC02	Multi-Function Controller w/ Basic, 2000 blocks and/or 1000 lines of Basic; I/O thru 64 slaves, use NTFM01, NIMF02	4
NMFC03	Multi-Function Controller	2
NMFC03	w/ 6638758A1 High Speed Redundancy Link	1
NMFC04	Multi-Function Controller	3
NMFC05	Multi-Function Controller	10
NMPC01	PC-90 Processor (replaced by IMMPC01)	0
NMPC02	PC-90 Processor w/ Basic (replaced by IMMPC01)	0
NPIM01	Processor Interface Module	0
NPTM01	Point Table Module	12
NQRC01	Enhanced Quick Response Controller	0
NQRC02	Advanced Quick Response Controller	0
NQRS01	Quick Response Slave	0
NQRS02	Quick Response Slave	0
NRIO02	Remote I/O Module	4
NSBM01	SuperLoop Bus Module, PCU to NLIS01 Communication Interface, requires NLIS01	3
NSCM01	Serial Communication	1
NSDM01	DC/DC Converter	4
NSIM01	Serial Interface Module	9
NSPM01	Serial Port Module	3
NSSM01	Superloop Serial Module	2
SLC01	Loop Command Single Loop Controller	0
SLC02	Loop Command Single Loop Controller SLC02100	0

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

TAS01	Auto-Synchronization Slave	2
TPS02	Turbine Protection Module	0
UC-AS3	Module, Assembly 6635655A1	2
6624860A1		2
6636345A1	OIU Module Mounting Unit and Power Entry Panel	5
6637801A2	Power Mounting Card Cage	0
6637804C1	MMJ Back panel	1
6639890B1	Relay Panel	0
6642016D2	Relay Panel	1
6642626C1	Backplane	1
IEFAN01	Fan Assembly 120v	2
IEFAN02	Fan Assembly 240V	0
IEFAN03	Fan Assembly 120V	0
IEFAN04	Fan Assembly 120v Redundant	3
IFEAN05	Fan Assembly 48VDC	0
IEFAN06	Four Fan Pack for CFE 240V	0
IEMMU01	Module Mounting Unit, Rear Mounting 12 Module Slots	19
IEMMU02	Module Mounting Unit	0
IEMMU04	Module Mounting Unit, 5 Module Slots	0
IEMMU11	Module Mounting Unit, Rear Mounting, 12 Module Slots	1
IEMMU12	Module Mounting Unit	0
IEMMU21	Module Mounting Unit, Rear Mounting, 12 Module Slots	0
IEMMU22	Module Mounting Unit	0
IMBLK01	Blank Faceplates	29
NRAI01	Relays	207
IPFAN11	Power System Fan, 120 VAC Input	2
IPFAN12	Power System Fan 240VAC	0
IPFAN13	Power System Fan, 125 VDC	0
IPFAN14	MPS II Fan Module	0
NFAN01	Fan Assembly, 120 v	0
NFAN02	Fan Assembly 240v	0
NFTP01	Field Termination Panel	11
NMMU01	Module Mounting Unit, Rear Mounting 12 Module Slots	20
NMMU02	Module Mounting Unit	0
NRAI01	Relay Panel	0
NRAO01	Relay Panel	0
NRDI01	Relay Panel	0
NRDO01	Relay Panel	0
NTMU01	Termination Module Mounting Unit (rear mounting)	4
NTMU02	Termination Module Mounting Unit (front mounting)	5
258603A1	Fans & Parts	2
IECAB01	General Purpose Cabinet Modules & Terminations	2
IECFE11	NEMA 4 Small Field Enclosure, wall mount, empty	1
NCPS01	Console Printer Surface	0

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

NCPI01	Console 15 Degree Wedge	0
664258A1	NCPI02 Console 45 Degree Wedge	3
NCWS01	Console Work	0
CBE01	Bus Extender, 24 vdc	1
NIAC02	Analog Calibration Termination Module, TC, use with IMAMM03, IMASM02, NIAI02	0
NIAC03	Analog Calibration Termination Module, RTD, use with IMAMM03, IMASM03, NAI03	0
NIAC04	Analog Calibration Termination Module, RTD, use with IMAMM03, IMASM04, NIAI03	0
NIAO01	Analog Output Termination Module, 8 outputs, use with IMAOM01, NKTU02	0
NIAI01	Analog Input Termination Module, TC, 8 Inputs, use with IMASM02, NKTU02	0
NIAI02	Analog Input Termination Module, TC, 8 Inputs, use with IMASM02, NKTU02	0
NIAI03	Analog Input Termination Module, RTD, 8 inputs, use with IMASM03, 04, NKTU02	0
NIAI04	Analog Input Termination Module, high level, use with IMASM01, IMFBS01, NKTU02	0
NIAI05	Analog Input Termination Module, IMASI03 8 input, use (2) with IMASI03, NKAS02	0
NIAM01	Analog Master Termination Module, use with NAMM02, NKTU01	0
NIAM02	Analog Master Termination Module, use with IMAMM03, NKTU02	0
NICL01	Communication Link Termination Module, use with INNIS01, NKLS02, INLIM03, NKLS04	17
NICS01	Control I/O Termination Module, use with IMCIS02, IMQRS02, NKTU02	8
NIDI01	Digital I/O Termination Module, use with IMDSI02, IMDSO0x, IMDSM0x, IMASO01, IMHSS03, IMFCS01, NKTU02	32
NIDO01	Digital Output Termination Module, use with IMLMM02, NKTU02 for outputs only	3
NIDS01	Digital Station Termination Module, use with NICS01, IIASC01, NKTD01	0
NIMF01	Multi-Function Controller Termination Module, use with NMFC0x, NKTM01	5
NIMF02	Multi-Function Controller Termination Module, use with NMFC0x, NKTM01	0
NIMP01	Multi-Function Processor Termination Module, use with IMMFP0x, NKTU02	2
NIMP02	Multi-Function Processor Termination Module (redundant), use with IMMFP0x, NKTU02	2
NIPL01	Plant Loop Termination Module, use with LIM/KTM	0
NIPT01	Infinet to Plantloop Local Transfer Termination	0
NIRL01	Remote Link Termination Module	0
NIRL03	Remote Link Termination Module, use with IMRIO02, NKTU02	0
NTAI01	Analog Input Termination Unit	12
NTAI02	Analog Input Termination Unit, TC & mV 16 inputs, use with 2 IMASM02, NKTU01, NKA01	37

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

NTAI03	Analog Input Termination Unit	15
NTAI04	Analog Input Termination Unit, RTD 16 inputs, use with 2 IMASM03/04, NKTU01	0
NTAI05	Analog Input Termination Unit, High Level 16 inputs, use with IMASM01, IMFBS01, NKTU01	7
NTAI06	Analog Input Termination Unit, 16 inputs, use with IMASIO3, NKAS01	14
NTAM01	Analog Master Termination Unit, use with IMAMM03, NKTU01 if required	2
NTAO01	Analog Output Termination Unit, 8 outputs, use with IMAOM01, NKTU01	12
NTCF01	Fiber Optic Communication System, Optic-to-Optic Termination Unit (3km fiber optic receive/transmit)	1
NTCF02	NTCF02 Fiber Optic Communication System, Optic-to-Electronic Termination Unit, (3km fiber optic receive unit/ electronic transmit)	1
NTCF03	Fiber Optic Communication System, Electric-to-Optic Termination Unit, (electric receive unit/ 3 km fiber optic transmit)	1
NTCL01	Communication Loop Termination Unit, use with INNIS01, NKSL01, INLIM03, NKSL03	1
NTCS01	Control I/O Termination Unit, use with IMCIS02, IMQRS02, NKTU01	42
NTCS02	Control I/O Termination Unit, use with IMCIS02, IMQRS02, NKTU01	50
NTCS03	Control I/O termination unit	0
NTCS04	Control I/O Termination Unit, use with IMCIS02, IMQRS02, NKTU01	45
NTCU01	Plant Loop to Computer Interface Termination Unit, use with INSIM01, NKTU01, part of INPCI01	9
NTDI01	Digital Input Termination, use with IMDSIO2, IMDSO0x, IMDSM0x, IMASO01, IMHSS03, IMFCS01, NKTU01	8
NTDI02	Digital Input Termination, use with IMDSIO2, IMDSO0x, IMDSM0x, IMASO01, IMHSS03, IMFCS01, NKTU01	0
NTDO01	Digital Output Termination	10
NTDO02	Digital Output Termination Unit, 8 outputs, relays not included, use with IMDSO04, NKTU01, relays	1
NTFB01	Fieldbus Module Termination Unit, 15 inputs, use with IMFBS01, NKTU01	1
NTHS03	Hydraulic Servo Termination Unit, use with IMHSS03, NKHS03	0
NTKR01	Contact Termination	0
NTLS01	Logic Station Termination Unit, use with IMDSM05, NKTU01, NDLS02, NKDS0x	11
NTMF01	Multi-Function Controller Termination Unit, use with INMFC0x, NKTU01 if required	2
NTMP01	Multi-Function Processor Termination Unit, use with IMMFP0x, NKTU01 if required	0
NTPL01	Plant Loop Termination Unit, use with LIM/KLM	31
NTRL01	Remote Link Termination used with NRIO01	0
NTRL02A	Remote I/O Termination Unit, Fiber Optic, use with IMRIO02, NKTLM01 (requires 2 adapters (1949384A1) if replacing existing NTRL02)	0
NTRL02B	Remote I/O Termination Unit	1
NTRL03	Remote Link Termination Unit, use with IMRIO02, NKLM01	4
NTSM01	Server Module Termination Unit, use with INESM01, NKSM01	0

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

NTST01	Time-Synch Termination Unit, use with IMSET01, INTKM01, NKST01	0
NTU-716	Digital Input Termination, 24V 0.1A	3
NTU-7C6/MO	I/O Control +24V 650mA Terminations	0
NTU-7Q2E	EM Relay Termination 24VDC 850mA	0
NTU-7Q2/R	EM Relay Termination 24VDC 700mA	1
1947415A1	Disk Controller OMTI 5200	0
ST225	OIU HD	3
TM252	OIU HD	1
	OIU 8" Floppy Drive	4
	OIU 8" Floppy Drive & Hard Drive Complete Assembly	1
1948018-1	3.5" OIS Floppy Drive (TEAC)	1
NIOX01	I/O Expander Card Assembly 6634165E1	21
IOXM	I/O Expander Card Assembly 663416P11E1	6
MFPM	OIU Card	1
NPIM01	Processor Interface Card Assembly 6631996K1	12
NMFP01	Multi Function Processor Card Assembly 6634163P1/N1	19
NMFP02	Multi Function Processor Card Assembly	0
NMFP03	Multi Function Processor Card Assembly 6634163A3H	8
NMKB01	Panel Mount Keyboard for NCRT06	0
NMKI02	MCS Keyboard Interface	0
IIADP02	ADP Panel, 32 pushbuttons 663986A1	4
6634335A2	ACDC Power Supply RT301-3 115VAC Input, 5V @60A, +-12V @ 5A output	1
6634340A1	OIU Power Entry, Module Mounting & Power Supply mounting unit...includes 6634335A1 Power Supply Mounting hardware	1
6634998B1	Auxiliary Engineering Keyboard	2
6636087E1	EWS Graphics Card	1
6638514A1	External Membrane Keyboard for OIS rev A10	6
6634967C1	Internal Membrane keyboard card	1
6635490A1	OIU Card Cage with Backplane 6635491A1	1
6638353A1	A2, A4, A5 OIU/OIS Peripheral connectors and power distribution	12
6637517A1	MCS Keyboard/CRT Interface	1
1947415A2	OIS Hard Disk Controller OMTI 5400	2
1947415A2	OIS Hard Disk Controller DeltaTech 520DB	0
1948018A1	OIS Floppy Disk Drive 5 1/4"	2
1948028A1	Multi-bus Memory Card	1
1948193A1	QIC-02 Portable External Magnetic Tape Drive for OIS	0
1948778A2	Digital DECXM-M	2
1948932A7	OIS Video Card for Single Monitor	1
1949759A1	Compaq ELSA GLORIA Synergy 8MB Graphics Controller	7
198932A5	Video Card for Dual Monitors	1
258617A1	Touch Screen Card Controller: includes NHKAC13004, 1947422A21001, 1948027A3H, 6618445A3, 6636352A2, NBZAC09006, 6636495A2	0
6634230K1	Membrane Keyboard Module	1

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

6636448A1	Annunciator Display Assembly	3
6634967C1	Annunciator Board	1
6637033A	SBE M68 CPU Multibus Card	1
6637033A2	SBE M68 CPU Multibus Card	2
6637033A3	SBE M68 CPU Multibus Card rev F3	3
6637033A4	SBE M68 CPU Multibus Card rev F3	3
6637257E1	Seagate HD + OMTI 5400 Controller Assembly	6
6637257E1	Seagate ST-4096 Hard Drive with Anti-Shock Mount	2
6638238F1	OIS Input Distribution Card Only	3
6638238F1	OIS Input Distribution Assembly including faceplate/mount w/ connectors and speaker	2
6638511E1	Electrographics E271-150C card for use with OIS IIMKM01 & IIMKM02	8
6638554A1	OIS 20 Floppy Drive Assembly 5 1/4" Floppy, Sound Board, Speaker	6
6638554A9	OIS 40 Floppy Drive Assembly, 3.5" Floppy, Sound Board, Speaker, other	1
6639030A6	OIS Keyboard Assembly (pizza box)	0
6640657D1	3 In-Line Fan Assembly OIC/OIS	4
6641376F1	OIS 40 Assembly; Power Supply/Floppy Disk Drive, Distribution	2
6643848A1	Compaq Flexor Processor for OIS 44	1
Alpha Station 255,	233 MHz from OIS 40 series Model PB47H-AA for OIS 43	0
DEC 3000	300X Model PE32A-AS from OIS for OIS 42	2
Digital VaxStation 4000VLC	Model YS48KDA	1
DEC Server 4000	60 Computer from OIS 41 Model VS46K-DA, CPU KA46, Series BA46A	1
IIAKB01	OIS Keyboard	0
IIAKB03	OIS Keyboard	0
IIAMS03	OIS Round Mouse	0
IIAMS04A	OIS Mouse	0
IIATB01	OIS Trackball	
IIATB02	OIS Trackball	
IATB03	OIS Trackball	
IIATS01	OIS Touch Screen Kit	
IIATS02	OIS Touch Screen Kit	
IIATS03	OIS Touch Screen Kit	
IIADP02	Annunciator Display Panel 32 Configurable Pushbuttons w/ LEDs	2
6636448A1	Annunciator Display Panel 64 Configurable Pushbuttons w/ LEDs	1
IICDD01	OIS CD Drive	0
IICPI02	OIS Wedge 45 deg	3
IIDMT05	DAT Drive	0
IIDMT06	DAT Drive	0
IIDOP02B	Optical Drive	0
IIDOP03B	Optical Drive	0
IIDST01	Streaming Tape Drive	0
IIDST04	Streaming Tape Drive	0
IIMCL01	Multibus Communication Link Termination, for infi-net/plant loop communication highway, for all OIS 6638438A1	9

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

IIMCP01	Multibus Communication Processor Infinet/Plant Loop 663822701	8
IIMCP02	Multibus Communication Processor, SCSI (Loop Module to OIS Interface, Infi-net) for OIS 41, 42, 25, MCS Plus	2
IIMGC01	Multibus Graphics Controller Matrox SX-900 Color Graphic Card, rev 02	12
IIMGC02	Hi Speed Multibus Graphics Card (640 x 480) to support one OIS CRT, Spare for MCS Plus	0
IIMGC03	Hi Speed Multibus Graphics Card (1024 x 768) to support one OIS CRT for OIS 25	0
IIMGC04	Hi Speed Multibus Graphics Card (1280 x 1024) to support one OIS CRT for OIS 25	0
IIMKM01	Multibus Keyboard Card for OIS	6
IIMKM01A	Multibus Keyboard Card for OIS includes Electrographics daughter card 6638511E1	4
IIMKM02	Multibus Keyboard Module 6638511A3 for OIS 40, 41, 42, 43	1
IIMKM02A	Multibus Keyboard Module for OIS	0
IIMLM01	Multibus Loop Module, Communication Highway to Communication Processor I/F for all OIS 6638230A1	2
IIMLM21	Multibus Loop Module	1
IIMPM01	Multibus Processr Module SBE MPU-28 rev E (Bailey ROM B-2) 1900214 Processor Card for OIS	11
IIMPM02	Multibus Processor Module for MCS Plus and OIS 25 663851102	2
1948023A1	SASX Interface Module (IIMP Daughterboard)	2
IIMRM01	Multibus Reset Module	2
IIMRM02	Multibus Reset Module (for driver cabinet) 663851061/6638511D2	9
IIMSM01	Multibus Serial I/O Module for OIS 20, 25 & MCS	9
IIMTM01	Termination Module	0
IIPRT02	Genicom 3410 Printer	0
L700797A1	Adaptec AHA-1542C/1540C SCSI Adapter Card (PC)	1
NADS01	Annunciator Display Select 64 pushbutton	0
6637801A2	OIS Card Cage and Backplane	9
1948118E1	Power Supply Card for CLCs	0
1948564A3	Power Supply FLU4-150-Series OIS Power Supply	1
6640038A2	Power Supply FLU4-150-Series OIS Power Supply	1
6638553V5	Power Supply FLU4-150-Series OIS Power Supply	1
6640038A1	Power Supply FLU4-150-Series OIS Power Supply	1
29101-169A	OIS 41 Power Supply	3
40PS3201A	DCU Power Supply w/ Battery	0
40PS3205A	DCU Power Supply	2
636325A1	Dual Power Supply	4
6634355A2	Power Supply 115v Input, 5v @ 60a, +-12 v @5a ACDC Model RT 301-3 for OIU 6636345A1	5
6635051G1	(OIU Power Supply) ACDC Model 801	8
6635051G2	(OIU Power Supply)	2
6635625A1	(OIU Power Supply) 15V	1
6638235A1	OIS Power Distribution Assembly (OIS)	4

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

664463A5	RPS Power Entry Panel	1
ACDC Model 801	OIU Power Supply 5v@10A, -12v @ 1.6A, 24v @ 2A	1
IEPAF01	MPS1 Field Supply Module 24v	14
IEPAF02	MPS Field Supply Module	14
IEPAS01	System Power Module	30
IEPAS02	System Power Module	13
IEPBM01	Power Bus Monitor	0
IEPDP01	Power Distribution Panel	4
IEPDS01	System Power Module, 24VDC Input, provides +5V(15A), +- 15V System or 24V(4A) I/O Power	0
IEPDS02	System Power Module	0
IEPEP01	Power Entry Panel, Single AC Feed	3
IEPEP02	Power Entry Panel	0
IEPEP03	Power Entry Panel, Redundant AC Feed	1
IEPFA02	Field Supply Module 24v	0
IEPMU01	Power Mounting Unit, Rear Mount	4
IEPMU02	Power Mounting Unit	0
IPBLC01	MPS2, Harmony Power Module	6
IPCHS01	I90 Power Module Chassis	4
IPCHS02	I90 Power Module Chassis	0
IPECB11	I90 Power Entry Circuit Breakers	3
IPECB13	I90 Power Entry Circuit Breakers	0
IPESW11	MPS2 Power Entry Switch	0
IPESW13	MPS2 Power Entry Switch	0
IPFCH01	I90 Power Fan Chassis	0
IPFLD01	MPS2 Field Power Module	8
IPFLD24	MPS2 Field Power Module	3
IPFLD48	MPS2 Field Power Module	0
IPFLD125	MPS2 Field Power Module, 125VDC 2.3A	3
IPMON01	I90 Power Monitoring Module	0
IPSYS01	System Power Module	6
6638565-1	OIS 20 Power Supply AC/DC RSF503B-2330	0
NIOP01	I/O Panel non-auctioneered, 120 VAC	0
NIOP02	I/O Power PANEL, 120 VAC; Mount two NPSI0x power supplies	4
NIOP03	I/O Power Panel, nonauctioneered, 240 VAC	0
NIOP04	I/O Power Panel, auctioneered, 240VAC	0
NIPS01	Integrated Power Supply 120 VAC	0
NIPS02	Integrated Power Supply 120 VAC	0
NIPS03	Integrated Power Supply 240 VAC	0
NIPS04	Integrated Power Supply 240 VAC	0
NMPP01	Module Power Panel, nonauctioneered	0
NMPP02	Module Power Panel, with Auctioneering; Mounts two NPSM0x Power Supplies	2
NIPS01	Integrated Power Supply	1

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com

Industrial Repair Services of Louisiana

A Manuel & Tedder Enterprise
17188 Airline Highway, Suite M-144
Prairieville, Louisiana 70769

NPEP01	Power Entry Panel, 120 VAC	3
NPEP02	Power Entry Panel, 120 VAC	5
NPEP03	Power Entry Panel	0
NPEP04	Power Entry Panel	0
NPSI01	I/O Power Supply, 24 VDC Output Lambda LRS-54-24 Power Supplies	6
NPSI02	ACDC Module Power Supply 120v ACDC Model RSF503B-2330-9021 115/220VAC 3 channel 5V@80A, 12V @ 8A, 12V @ 8A	5
NPSI02	Pioneer Magnetics Power Supply 120v 3 channel PM2972A-3-3	1
NPSI03	I/O Power Supply 24 vdc	8
NPSI04	I/O Power Supply, 125 VDC output	0
ACDC fModel RT301-3	OIU System Power Supply,	3
NPSM01	System Power Supply, 120VAC 50/60Hz Input 375W	0
NPSM02	System Power Supply, ACDCX Model 804B-2448-0000 4 Channel 5V 100A, 15V @ 7A, 15V @ 7a, 30.5V @ 1A	0
NPSM03	System Power Supply, 240VAC 50/60Hz Input, 375 W	0
NPSM04	System Power Supply, ACDC Rev 804B-2448-0000 4 Channel, 5V @ 100A, 15V @ 7A, 15V @ 7A, 30.5 V@1A	0
NPSM02	System Power Supply, 120 VAC 750 Watts, Pioneer Magnetics 5V@100A, 15V@7A, 15V@7A, 30.5V@1A	0
NSPS01	Network 90 Integrated Power Supply/Power Distribution Mini90	1
NSPS02	Network 90 Power Supply	0
Pioneer Electronics	PM2974A-1-4	1
OIS 11	Power Supply	1
OIS 41	Power Supply 29101-169A rev B4	17
6637826B1	AC Transfer Module for use w/ IEPEP03, NPEP05	12
6637830F1	Bus Monitor Module for use w/ IEPEP03, NPEP05	6
6632094A1	NPEP01 Circuit Board	1

Industrial Repair Services of Louisiana does not sell or provide software licensing for any items sold. All software is property of the original manufacture and must be purchased from them directly. All firmware and proprietary information is sole property of the OEM and we do not provide or sell any such items.

For the latest list please visit us at: www.irsla.com

Email Sales: sales@irsla.com

Industrial Repair Services of Louisiana
A Manuel & Tedder Enterprise
17188 Airline Highway Suite M-144
Prairieville, Louisiana 70769

Phone: 800-791-1756
Fax: 225-673-6419
Email: sales@irsla.com
Web Site: www.irsla.com